
Metal Big Gear Wall Clock


Art. No.: 25 018

Instruction Manual



1. Instruction:

a) Assemble the quarter wheel according to below:



b) Put the hour hand on the gear as shown on below picture



c) Battery:

Open the battery cover and insert 2pcs C-size batteries and close the cover.

d) Time

The minute hand and Hour hand are separate. Please set the time as follows:

Example: When setting 1:00PM, please turn the minute setting knob to make the minute hand pointing "00" Minute, and turn the hour setting knob to make the hour hand pointing 1 Hour.

2. Product information:

Accuracy	Operating Temperature	Range	Battery
Average monthly difference ±90 seconds	-10°C + 50°C		2 SIZE C

3. WARNING:

- Hang the clock **vertically** on wall **before** setting the time
- Set the clock only to the full hour
- Install the batteries in the correct direction
- Change batteries if the clock stops moving
- Do not dismantle the clock

DISPOSAL:

The packaging material is reusable. Dispose of the packaging in an environmentally friendly way by putting it in the appropriate recyclable waste collection containers.





Dispose of the product and the batteries in view of the environment if you want to separate. The device and the batteries must not be thrown in with domestic waste. Take them to a recycling center for used electrical and electronic devices. For more information you can consult your local government. Remove batteries first.

Eurotops Versand GmbH Elisabeth-Selbert-Straße 3 40764 Langenfeld, Germany 7



If technical support is needed, please call ...

in Germany 0180 . 530 63 63* or info@eurotops.de in Austria 01 . 230 60 43 12 or info@eurotops.at in Switzerland 044 . 28 36 125 or info@eurotops.ch in the Netherlands 026 . 37 36 333 or info@eurotops.nl in France 0892 . 700 470** or info@eurotops.fr

A possible return of products should be addressed to the return address stated on your invoice.

The manual only reflects the technical conditions available under printing. Any changes in technology and equipment are reserved.

© 08.08.2014

^{* 14} Cents/minute via German landline, max. 42 cents/minute via mobile phone network

^{**34} Cents/minute via French landline