


AUTOMATIC 3 HAND DATE

(18) - Date calendar

(a) - Normal running and manual winding position (turn clockwise)

(b) - Date adjust (turn anti-clockwise). Watch runs

(c) - Hand-setting



AUTOMATIC 3 HAND DAY/DATE


(DAY) - Weekday calendar

(18) - Date calendar

(a) - Normal running and manual winding position (turn clockwise)

(b) - Date adjust (turn anti-clockwise). Day adjust (turn clockwise). Watch runs

(c) - Hand-setting



AUTOMATIC 3 HAND DAY/DATE

(DAY) - Weekday calendar

(18) - Date calendar

(a) - Normal running and manual winding position (turn clockwise)

(b) - Date adjust (turn anti-clockwise). Day adjust (turn clockwise). Watch runs

(c) - Hand-setting